

DENON®

PMA-2500NE

INTEGRATED AMPLIFIER

Quick Start Guide

Kurzanleitung / Guide de démarrage rapide / Guida di Avvio Rapido /
Guía de inicio rápido / Snelhandleiding / Snabbstartsguide /
Краткое руководство пользователя / Skrócona instrukcja obsługi

Read Me First....

Bitte zuerst lesen... / Lisez-moi en premier.... / Nota preliminare.... /
Lea esto primero.... / Lees mij eerst... / Läs detta först... /
Прочитайте в первую очередь... / Przeczytaj to najpierw....

ENGLISH

DEUTSCH

FRANÇAIS

ITALIANO

ESPAÑOL

NEDERLANDS

SVENSKA

РУССКИЙ

POLSKI

Welcome

Thank you for choosing a Denon amplifier. This guide provides step-by-step instructions for setting up your amplifier.

Please do not return this unit to the store – call for assistance.








If you need help... :

If you need additional help in solving problems, contact Denon customer service in your area.


For details, see the Denon homepage. www.denon.com

Before You Begin


What's In the Box

Quick Start Guide		Power cord	
Owner's Manual		Remote control unit	
Safety Instructions		R03/AAA batteries	
Integrated Amplifier			

Required for Basic connections



Optional




These drawings are for illustrative purposes only and may not represent the actual product(s).

Setup


There are seven steps to the setup process.

- 1** Install batteries in the remote control unit
- 2** Connect the speakers to the amplifier
- 3** Connect the CD player to the amplifier
- 4** Plug the power cord into a power outlet
- 5** Begin CD playback
- 6** Installing the Windows driver software
- 7** Enjoying music using PC or Mac

1 Install batteries in the remote control unit



2 Connect the speakers to the amplifier



Connecting the speaker cables

① Peel off about 10 mm of sheathing from the tip of the speaker cable, then either twist the core wire tightly or apply solder to it.



② Turn the speaker terminal counterclockwise to loosen it.




③ Insert the speaker cable's core wire to all the way into the speaker terminal.




④ Turn the speaker terminal clockwise to tighten it.




3 Connect the CD player to the amplifier




4 Plug the power cord into a power outlet





Connect to household
power outlet
(AC 230 V, 50/60 Hz)



Power cord (supplied)



5 Begin CD playback




6 Installing the Windows driver software

1 Download the dedicated driver from the “Download” section of the PMA-2500NE page of the Denon website (<http://www.denon.com/pages/home.aspx>) onto your PC.

2 Unzip the downloaded file, and double-click the exe file.


3 Install the driver.

- ① Select the language to use for the installation.
- ② Click “OK”.



- ③ The wizard menu is displayed. Follow the instructions on the screen.

- ④ When the wizard is completed, click “Yes”.




NOTE

- Mac users will use the built-in driver software. No installation is required.
- The driver software cannot be installed correctly if your PC is connected to the unit by a USB cable.
- If the unit and your computer are connected by a USB cable and the computer is switched on before installation, disconnect the USB and restart the computer.
- Please see the FAQ at www.denon.com if you experience any issues getting audio to play from your computer through the PMA-2500NE. You may also want to check the support pages for your audio player application.

7 Enjoying music using PC or Mac

❑ Connect to PC or Mac

1 Connect to PC or Mac.




2 Press on this unit.

- When the unit power is turned on, the computer automatically finds and connects to the unit.

❑ Listen to PC or Mac Audio

1 Press INPUT SELECT to change the input source to “USB-DAC”.




2 Set the audio signal destination to this unit on the computer.


[Windows OS]

- ① Click the “Start” button and click “Control Panel” on the PC.
 - The control panel setting list is displayed.
- ② Click the “Sound” icon.
 - The sound menu window is displayed.

- ③ Check that there is a checkmark next to “Default Device” under in “Digital Audio Interface PMA-2500NE” of the “Playback” tab.
 - When there is a checkmark for a different device, click “Digital Audio Interface PMA-2500NE” and “Set Default”.
- ④ Select “Digital Audio Interface PMA-2500NE” and click “Properties”.
 - The PMA-2500NE Properties window is displayed.




- ⑤ Click the “Advanced” tab.
- ⑥ Select the sampling rate and bit rate to be applied to the D/A converter.
 - It is recommended that “2 channel, 24 bit, 192000 Hz (Studio Quality)” is selected (Windows 7).
 - It is recommended that “2 channel, 32 bit, 192000 Hz (Studio Quality)” is selected (Windows 8/8.1).
- ⑦ Click “Apply”.
- ⑧ Click “Test”.
- Check that audio from this unit is output from the PC.




[Mac OS X]

- ① Move the cursor to “Go” on the computer screen, and then click “Utilities”.
 - The utility list is displayed.
- ② Double-click “Audio MIDI Setup”.
- ③ Check that “Use this device for sound output” is checked in “PMA-2500NE”.
 - If a different device is checked, select and “Secondary click” on “PMA-2500NE”, and then select “Use this device for sound output”.



- ④ Select the “PMA-2500NE” format.
 - It is normally recommended to set the format to “384000.0 Hz” and “2ch-32 bit Interger”.



- ⑤ Click “Quit Audio MIDI Setup”.

3

Use your favorite music applications on your PC/Mac to play audio through the PMA-2500NE.

- For high resolution audio playback you will need to obtain an advanced audio player software such as JRiver Media Center or Audirvana.

USB: PCM
192kHz

The type of music file and sampling frequency are displayed.

4

Adjust the volume.



NOTE

Additional settings to output audio to the PMA-2500NE may have to be selected in your advanced audio player application. Please refer to the user's manual for your application.



Please refer to the owner's manual about the required specifications of suiting computer.

Owner's Manual

Please reference to the Owner's Manual for more details about the setup and operation of the amplifier and its features.

Online Version

Enter the following URL into your web browser:
manuals.denon.com/PMA2500NE/EU/EN/



Online Manual




Printable Version

Access the print version of the owner's manual from the included CD-ROM or select the "PDF Download" link from the Online Version.

1

Insert the disc into your PC.



2

Follow the screen or double click on the PDF file.

DENON®
www.denon.com

Printed in Japan 5411 11338 00AD
Copyright © 2015 D&M Holdings Inc. All Rights Reserved.